

(Original) Use and maintenance manual

Type: Auto-Puncher for timing belts
Model: APTM-600



IMPORTANT

Carefully read this User Manual and follow the instructions and warnings before operating the machine.

Any modification or change may cause the loss of warranty and manufacturer liability.

This Manual should always be stored the machine and visible for operators and maintenance technicians for any future reference. The Manual is part of the machine.

Index:

Page

-	CE Declaration of conformity:	3
-	Transport and unloading the machine	4
-	Dimensions and weights:	5
-	Installation and connection:	5
-	Description:	6
-	Technical characteristics:	7
-	Using instructions:	7
	<i>Safety Systems and messages.</i>	<i>7</i>
	<i>Programming.</i>	<i>8</i>
	<i>Belt cutting measurements for the different punches.</i>	<i>10</i>
	<i>Changing punch.</i>	<i>10</i>
	<i>PUNCH CUTTING A-A direct finger:</i>	<i>11</i>
	<i>Changing support plate:</i>	<i>16</i>
	<i>Maintenance and care:</i>	<i>18</i>
-	Troubleshooting:	18
-	Pneumatic scheme:	20
-	Spare parts:	21
-	Electrical schemes	25

- **CE Declaration of conformity:**

WE DECLARE, under our responsibility, that the machine:

- Type: Automatic Puncher
- Brand: ERM Engineering
- Model: APTM-600
- Serial No.: xxxxxx
- Manufacturer date: 2021

Inspired by the directives of the Official Journal of the European Communities:

2006/42/CE Machinery Directive

2014/35/UE Low Voltage Directive

2014/30/UE Electromagnetic Compatibility Directive

Complies with the design and construction specifications of the European Standards on General Machine Safety:

EN 349 - EN 614-1 - EN 614-2 - EN 1005-1 - EN 1005-2 - EN 1005-3 - EN 1005-4 - EN 14118 - EN 12100 - EN 13850 - EN 13857 - EN 14118 - EN 14120 - EN 60204-1 - EN 11161 - EN 61310-1 - EN 13849-1 - EN 13849-2 - EN 60204-1

General Manager: Eduardo Ramos Martínez



ermengineering
belting fabrication equipment

Arenys de Munt (Barcelona)-SPAIN

Date: 2021/08

- **Transport and unloading the machine**

Due to the fragility of some components of the machine, wood packaging is required with reinforced board to attach it to the base by bolts through the openings in the rubber feet.



To keep the weight of the load well balanced, moving the punch cutting head to halfway across its run before proceeding to pack is recommended.

For sea transport, the linear rails and drive screw located at the bottom of the cutting head must be lubricated and full plastic cover provided.

A pallet truck must be used to move the machine, lifting it by the bottom cross bars of the bench just as shown in the picture.




Fit the four rubber feet and proceed to level.



- **Dimensions and weights:**

- Total weight: 314 Kg
- Measurements: 1487x1060x1538 mm.




- **Installation and connection:**

Provide compressed air through a tube with a minimum interior diameter of 8 mm., connected to the intake.



NOTE:

One must bear in mind that the air consumption of this punch cutter is 280 litres/minute. Connect the power cable to the control board at 230v monophasic.



NOTE:

It is recommendable for the air and power lines to be run from above to prevent the staff tripping or falling.

- **Description:**

Pneumatic punch cutter with a motorised head to cut conveyor belts in zigzag, with ball screw activated by a stepper motor and positioning control. Pressure and punch cutting time control.

Exchangeable cutting heads for different cutting geometries, with the possibility of programming diverse forward steps.

Support bench with material positioning guides.

This punch cutter is especially designed to cut thermoplastic materials with interior fabric.

- **Technical characteristics:**

Dimensions	1487 x 1060 x 1538 (l x w x h)
Weight	314 Kg
Max. thickness	10 mm.
Voltage	1 x 230
Power	0.40 kW
Max. pressure	9 bar
Belt width	620 mm.
Advance speed	1 meter/minute

- **Using instructions:**

WARNING:

HAND AND ARM TRAPPING HAZARD WITH THIS DEVICE DUE TO THE MOVEMENT OF THE CUTTING HEAD. GREAT CARE MUST ALSO BE TAKEN BETWEEN THE CUTTING HEAD AND SUPPORT PLATE, AS THERE IS THE DANGER OF LIMBS BEING SEVERED.

Once the machine electrical and air connections are made, proceed to start it up using the ON switch.



Check that the regulator pressure is between 2 and 6 bar according to the cutting head installed.



Safety Systems and messages.

This punch cutter has been equipped with the following safety systems:

2. EMERGENCY STOP

This system allows an emergency stop to be performed at any time using the two push buttons located at both ends of the bench.

Message: EMERGENCY LOCK PUSH BUTTON

To deactivate it, we must unlock the push button and then press RESET to return the head to the starting point.

2. TREAD BAR

This device does not allow engagement of the cutting head if the bar holding the belt is not lowered.

Message: TREAD BAR

To deactivate it, all one need do is lower the bar and press START.

3. DOOR OPEN

This device detects that the rear door of the blade head is open.

Message: DOOR OPEN

The door must be closed to deactivate it.

4. CYLINDER DETECTOR

This device does not allow displacement of the head because it detects that the cutting cylinder is not raised. This may happen due to lack of air or failure of the detector.

Message: CYLINDER DETECTOR

To deactivate it, provide the machine with air or replace the detector.

Programming.

We must know the functions of the push buttons on the board to program the punch cutter.



1. RESET

This must be pressed after an emergency stop or position the head at the starting point after STOP.

2. A-A

Selection of the A-A program

This program is used in most cases, to always operate on guide rail and cut the belts performing the first end by inserting it on one side of the bridge and the second end on the other side, or to cut series continuously.

3. A-B

Selection of the A-B program to do individual operations.

4. STOP

Allows the cutting process to be halted at any moment, to change the time or cutting pressure, for example.

On pressing START, it will continue the process without losing the positioning memory.

5. START

Starts the cutting process or acts to reboot following a stop.

6. MENU

This button is to jump from one programming field to another and thus amend the values:

- Belt width
- Step
- Cutting time

7. + / -

To increase or decrease the marked field values.

8. OK

To validate the modified value. Any modification must always be validated.

Belt cutting measurements for the different punches.

120 x 15 90 °..... 135 mm. Longer

Changing punch




WARNING:

When changing punches, switching off the equipment at the OFF switch is recommended for greater safety.

Open the sliding door.



Loosen the 2 bolts using a 13mm. spanner.



Take out the punch and insert the new one.



Retighten the 2 bolts.

Close the sliding door and program the correct step in the MENU STEP ... OK

NOTE:


The cutting pressure must be adjusted for each type of punch or material.

If not, excess pressure may cause the blades to break or premature wear of the cutting aluminium board.




PUNCH CUTTING A-A direct finger:

Write with pencil a line at 100mm approx. from the beginning of the belt.




Take this line like 0 of total length of final endless measure.




Then pencil in the exact measure required. (In this case 540mm)



Then place the belt to left side of machine, under the tread bar and adjust the table guide.



Introduce the belt until the mark made coincides with laser line, ensuring it is fully in contact with the guide.



Lower the tread bar using the down push button.



Check that belt still in correct position after down the bar.
Select the A-A function if not activated.



Use the + / - buttons to adjust the belt width in centimeters and then press OK.



Check the STEP is correct. If not, use the MENU button to skip the STEP and input the required value with + / - and then press OK.



NOTE:

The programmed values will not be lost, even if the equipment is switched off. The program always memorises the last values input.


Press START to begin cutting at the first end.

NOTE:


No programmed value may be changed during the cutting process, except the cutting time. To do so, press STOP, change the value, and then press START to continue.

Once the first cut is completed, release the belt by pressing the bar raise button.

Place the second end of the belt by the Right side by the guide and position.




And the pencil line of the belt just by the laser mark or 1/2mm more inside depending on the thickness belt.



Lower the tread bar using the drop push button and press START.

Changing support plate:


The black cover is removed to change or turn the support plate.
For this operation, use an Allen key 6mm.



Fully remove the plate displacement nut.



Use a screwdriver to lever in the jig opening to lift and withdraw the plate.



Remove the plate from the back side of the frame.

Maintenance and care:

- Keep the screw and linear guides dust free and well lubricated with low density, low silicone content lubricant oil.
- Replace the blades or the polypropylene bench when imperfect cuts are observed.
- Periodically move the polypropylene base 2 or 3 mm. to even out the wear.
- Empty out the water and clean the air intake filter basin if there is condensation in the line.

- Troubleshooting:

The board does not turn on.

Check whether the switch LED turns red to determine a possible problem in the electric power line to the machine.

The head does not move at all.

Check that the cylinder is upward and that the grid (cylinder cutting detector) is on.

The head moves but does not cut.

Check that the electro-valve is working and that the connector LED is on.

Check that the regulator pressure is above 2 bar.

Check that the cutting time is programmed between 05 and 10.


The belt is not cut across the full width.

Check that the intake pressure does not drop during cutting due to compressed air supply shortage.

Check the thickness of the polypropylene plate.

NOTE: In the event of any problem, pay special attention to the messages on the screen to find what is wrong.


- **Pneumatic scheme:**



- **Spare parts:**


PUNCHING PLATE 120X15

Number	Part name	Units
Kn77101	cuchilla 0.7x122xdouble bisel normal.par	2
70200	Distancial troquel 120 DC.par	1
m_443_11_ae_v0.par		1
70220	Pasador troquel.par	2
67101	TROQUEL-120X15.par	1



PUNCHING PLATE 80X10

Number	Part name	Units
Kn77102	cuchilla 0.7x82xdouble bisel normal.par	2
70200	Distancial troquel 120 DC.par	1
70220	Pasador troquel.par	2
67102	TROQUEL-80X10.par	1




Use and maintenance manual

Auto-Puncher for timing belts

Model: APTM-600

Number	Part name	Units
70101	Ala brida.par	1
70201	Base distancial.par	1
70205	Base patines.par	1
70100	00Q28140TF-400CZ.asm	1
70200	Distancial troquel 120 DC.par	1
70202	Enlace troque AFP.par	1
70103	KQ2L12-03S.par	2
70211	m_443_1L_ae_v0.par	1
70102	Patin Hlwh 20.par	4
70203	Pestana troquel.par	2
70213	Postizo troquel.par	1
70204	Soporte guia cabeza.par	1
70104	Tapa cilindro.par	1




Use and maintenance manual


Auto-Puncher for timing belts

Model: APTM-600

Number	Part name	Units
100100	Barra pisador.par	1
100101	C02B25_400_0_.par	2
100102	Placa C02 pisador.par	2
100104	Cinta pisador.par	1
100107	K02L04_M5.par	4
100108	Aluminio pisador.par	1
100109	Goma pisador.par	1



- **Electrical schemes**




Use and maintenance manual

Auto-Puncher for timing belts

Model: APTM-600


0 1 2 3 4 5 6 7 8 9



Use and maintenance manual

Auto-Puncher for timing belts


Model: APTM-600



Use and maintenance manual

Auto-Puncher for timing belts

Model: APTM-600



Use and maintenance manual

Auto-Puncher for timing belts

Model: APTM-600

